



## ECCOBORDER FLEX PANEL

ECCO PRODUCTS



### Quick & easy installation

01

#### Preparation

Dig a trench following the chosen installation shape. ECCOborder Flex Panel is a 2m40 straight slat that is ideal as a sleek and tight border.



02

#### Placement

Place the ECCOborder Flex Panel at least  $\frac{2}{3}$  into the ground, in the trench that has been provided for that purpose. You can install the ECCOborder Flex Panel with a flat or rounded top edge, depending on your choice.



03

#### Anchoring

Hammer the Multi Profile fixing posts into the ground using a rubber or wooden mallet. The Multi Profile anchoring ensures increased stability. The top of the posts should be about 3 cm lower than the top edge of the ECCOborder Flex Panel.



04

#### Mounting

Depending on the application, we recommend anchoring every 80-100 cm. **ADVICE:** Attach the ECCOborder Flex Panel to the Multi Profile posts with self-drilling countersunk screws, length 45 mm.



05

#### Finish

Complete both sides of the border with soil, bark or gravel according to the chosen application.

